

When mounting this product & drilling holes, the installer MUST be sure that no vehicle components or other vital parts could be damaged by the drilling process. Check both sides of the mounting surface before drilling begins. Also de-burr any holes and remove any metal shards or remnants. Install grommets into all wire passage holes.



**PRODUCTS COMPANY**804 East Hwy 248Cassville, MO 65625U.S. and Canada Toll Free NumbersPhone: 800-641-4098 FAX: 800-526-1240E-mail: sales@able2products.comWEB: www.able2products.com